

## **Thank you and congratulations on your purchase of a 20" Willy Sidewalker.**

The Willy Sidewalker comes 70% pre-assembled. Below are the final assembly instructions. ***They are intended for DIY customers.***

NOTE: If any part of the instructions is unclear, or if you are new to final bike assembly and are unable to get help from a friend, or if you prefer to let a professional do it, we recommend that you take the Willy Sidewalker to a local area bike shop for final assembly and safety inspection. (It is approximately 20 to 30 minutes work for a bike mechanic.)

You will need: #6 and #5 Allen key, wire cutter.

### **PACKING LIST:**

Open the box and ensure you have the following:

- 1) Frame with front and rear brakes, attached foot platform, rear brake cable/cable housing.
- 2) Two identical wheel sets
- 3) Handlebar/stem with hand grips, brake levers and bell.
- 4) Small box or plastic bag with hardware inside.
- 5) Front and rear wheel fenders.

Inside the small box or plastic bag:

- 1) Quick release hubs, front and rear
- 2) Front brake cable/cable housing.
- 3) Screws for fenders, front and rear.
- 4) Reflector with nut and washer.
- 5) Two 90 degree "noodles": the rigid one for front brake, flexible one for rear brake.
- 6) Two cable ends.

### **THE FINAL ASSEMBLY:**

1) Wheels: Insert quick release hub and position wheel into the front fork and tighten. Repeat for rear wheel.

2) Handlebar/stem assembly: Slide the handlebar/stem into the downtube to desired height, and lock with #6 Allen key.

3) Front and rear brake assembly: a) Use this link as a guide:

<http://pedalwithapurpose.wordpress.com/2010/11/02/brake-essentials/>

4) Rear brake: At the handle bar, slightly release the locking nut with #5 Allen key. Insert the long cable-end into the right handle bar brake lever, then adjust and tighten locking nut. Test rear brake lever for proper tension and correct action.

5) Front brake: Repeat above procedure for front brake. Test front brake lever for proper tension and correct action.

6) Cut access cable with wire cutter. Attach and press cable end.

7) Install reflector with nut and washer on front bracket.

8) Pump 55 psi into the wheels, and check the brakes.

9) Fender assembly is optional. Use the Philips screws that are in the plastic bag. For the front fender, use two Philips screws, one for each stay, and one bolt, washer and nut for connecting to the front fork. For the rear fender, use two Philips screws, one for each stay, and a third screw for connecting to the frame.

Having problems? email us at  
[kickstartscooters@yahoo.com](mailto:kickstartscooters@yahoo.com)  
or call 416-702-3636

***HAPPY SCOOTERING!***